SUITABLE FOR 25KV AC TRACTION

HALDWANI
(HDW)
CLASS B
STD-II

N

UP

C — CONTROL KEY FOR SB BARRIER
CHG — CRANK HANDLE FOR ELB
N R — SIGNAL SWITCH (1)
R N — SIGNAL SWITCH (2)
GATE WARNING HOOTER
GATE OPERATION PANEL

KATHGODAM (KGM) Km. 6.44

D01

DN. GATE SIG. B1 — 'A' ROAD USER SIGNAL — C OR 'CE' — GL — PANEL

GATE SIG. B2 — ROAD USER SIGNAL — L-XING NO. 54(INT.) CH: 935.00 DHE KM.83/23-24

BR. No.78 CH:549.50

C01T (5RAILS)

C01 S01 L-3 L-2 L-1 — KGM-HDW 1T AC1 AC2 — SB2 — 'B' ROAD USER SIGNAL

S12 (HASSDAC) — CONTROLLED BY BPAC USING BLOCK PANEL WITH UFSBI

4/6/8T — 101 — GL — N OR NE — SB1 — L-XING NO. 53(INT.) CH: 333.60 (301) — ROAD USER SIGNAL

101T — L-7 CATCH SIDING CSL-400.00m

℄ OF STN BUILDING CH:0.00 — Km. 82.955 Fm RMU DHE KM.82/28-83/1

105A — CSL-700.96m — HIGH LEVEL PASSENGER PLATFORM — L-3 03AT 03BT

S08 — 105B — 105T — CSL-693.55m — L-2 02AT 02BT — FOB

S04 — CSL-708.21m — L-1 01AT 01BT — B.G. PASSENGER PLATFORM

103B — 103T — 103A — S06 — S.B. — GOODS SHED — L-4 CSL-291.00m — L-5 CSL-361.00m

RL PLATFORM — L-6 CSL-350.00m — RL PLATFORM

ROAD USER SIGNAL

'C' ROAD USER SIGNAL — SB2 — S.B. BARRIER — B2 — ELB

SH45 — S05 — SH43 — SH47 — S03 — S07 — 102A — SB — T/2 — SH49 — 108X — 104A — 104T — 102T — 102B — 104B — 106A — 106AT — 106BT — 106B — 3/5/7T — SH42 — SHUNTING NECK CSL-245m — LINE-8 — DE

T/1 — GL — B1 — ELB — SB1 — S.B. BARRIER — L-XING NO. 52 'C' CH: 587.80 (302) DHE KM.82/9-10

1 IN 260 1 IN 70 — CH:755

GATE 51 DISTT./ADV. STR. 'G' ASPECT CONTROLLED THROUGH BPAC WITH UFSBI & 'Y' OR 'G' ASPECT GATE SIGNAL No. 2 OF L-XING GATE No. 51

HDW-LKU AC1 AC2 — S11 — C' D' (HASSDAC) — L-3 S02 C02 — L-2 — L-1 — 2T — C02T (5RAILS) — D02

L-XING 51 GATE SIGNAL (BETWEEN HDW-LKU) 3

LALKUAN (LKU) Km. 16.09

KGM | BLOCK PANEL — BLOCK PANEL | LKU

BPAC USING BLOCK PANEL WITH UFSBI

'Z' 'Z' — KEY 'Z' RELEASED IN TGT POSITION OF BPAC (HDW-KGM)

Y 'Y' — KEY 'Y' RELEASED IN TCF POSITION OF BPAC (HDW-KGM)

N OR NE — CONTROL FROM PANEL FOR SB BARRIER
Q — CONTROL FROM PANEL
GATE WARNING HOOTER
GATE OPERATION PANEL (CONTROLLED BY 301)
'Q' OR 'QE' CHG1 — 2-WAY LOCK BOX
QNE — QE NE — 3-WAY LOCK BOX — (KEY 'QNE' RELEASES KEY 'QE'&'NE')

M — CONTROL FROM PANEL FOR SB BARRIER
R — EMERGENCY CONTROL FROM PANEL
GATE WARNING HOOTER
GATE OPERATION PANEL (CONTROLLED BY 302)
'R' OR 'RE' CHG2 — 2-WAY LOCK BOX
RME — RE ME — 3-WAY LOCK BOX — (KEY 'RME' RELEASES KEY 'RE'&'ME')
'M' OR 'ME' — K1 K2 — 3-WAY LOCK UP BOX — (KEY 'M' RELEASED BY KEY 'K1'&'K2')