SUITABLE FOR 25KV AC TRACTION

LEVEL

UP

BHOJIPURA
(BPR)
CLASS B
STD-IIR

℄ OF STN BUILDING
CH: 19025 (FROM BRY)
CH: 0.00
Km. 300/5-6 (FROM LJN)

N

PILIBHIT Jn.
DIVNAPUR (HALT)
Km. 8.05
SETHAL CLASS 'B'
Km. 12.48

LALKUA Jn. (LKU)
DEDRANIA (DRN) CLASS 'B'
Km. 14.88
ATAMANDA (HALT) (AMA)
Km. 7.64

FROM BAREILLY Jn. (BRY)
IZATNAGAR (IZN) 'B' CLASS
Km. 12.07
DOHNA (DOX) 'B' CLASS
Km. 4.43

MEDIUM LEVEL PASSENGER PLATFORM

HIGH LEVEL PASSENGER PLATFORM

S.B.
SM'S PANEL

RAMP/TROLLY PATH

CSL-743.00 m 05T
CSL-716.65 m 04T
CSL-720.00 m 03T
CSL-730.00 m 02T
CSL-730.00 m 01T
CSL- 187.00m L6
HOT AXLE/TTM SIDING

BR. No. 319
Km. 300/2-3
CH: 304.00
CH: 19329.00
(FROM BAREILLY)

BR. No. 1
Km. 0/6-7
CH: 638.00

BR. No. 2 Km. 1/12-13
(CH: 20883.00 FROM BRY

BR. No. 320
Km. 301/8-9
CH: 17630.00
FROM BRY

BR. No. 321
Km. 302/0-1
CH: 17462.00
FROM BRY

L-XING No. 1 (INT.)
Km. 0/5-6
ch: 610.00

L-XING No. 228 (INT.)
Km. 299/8-9

L-XING No. 229 (INT.)
Km. 301/4-5 CH: 757.00
CH: 18268.00(FROM BRY)

L-XING No. 229A(INT.)
Km. 301/8-9
CH: 413.00

L-XING No. 230(M.)
Km. 303/3-4

CONTROL FROM PANEL FOR S.B. BARRIER
GATE WARNING HOOTER
EMERGENCY CONTROL ON L-XING No. 229
GATE OPERATION PANEL
'Q' OR 'QE' CHG2 ← CRANK HANDLE FOR MANUAL OPERATION OF ELB
'R' OR 'RE' CHG3 ← CRANK HANDLE FOR MANUAL OPERATION OF ELB
'S' OR 'SE' CHG4 ← CRANK HANDLE FOR MANUAL OPERATION OF ELB
EMERGENCY CONTROL ON L-XING No. 229A
CONTROL FROM PANEL FOR S.B. BARRIER
ROAD USER SIGNAL
SLIDING BOOM BARRIER
'C'
'B1'
CAT-I
CAT-II
CAT-III
(HASSDAC)
(DUAL SSDAC))
CABIN
BLOCK PANEL
SETHAL
DEDRANIA
DOHNA
BPAC BLOCK PANEL WITH UFSBI
SINGLE LINE BPAC BLOCK PANEL WITH UFSBI
UP SHUNTING KEY
UP SHUNTING KEY
DN SHUNTING KEY
CONTROL FROM PANEL FOR S.B. BARRIER
EMERGENCY CONTROL ON L-XING No. 1
GATE WARNING HOOTER
GATE OPERATION PANEL
'P' OR 'PE' CHG1 ← CRANK HANDLE FOR MANUAL OPERATION OF ELB
CESL-BAR
L-T TOWER WAGON SHED